

E988 OSD default setting

| Menu / Sub Menu | Default |
|-----------------------|-------------------------|
| Video | |
| Picture Mode | Energy Savings |
| Advanced Video | |
| Aspect Ratio | Normal |
| Overscan | Off |
| Dimming Setting | Depends on Picture Mode |
| Color Temperature | Depends on Picture Mode |
| Noise Reduction | Depends on Picture Mode |
| Adaptive Contrast | Depends on Picture Mode |
| Gamma | Depends on Picture Mode |
| Ambient Light Sensing | Depends on Picture Mode |
| Color Enhance | Depends on Picture Mode |
| HDR Mode | Depends on Picture Mode |
| Backlight | Depends on Picture Mode |
| Contrast | Depends on Picture Mode |
| Video Black Level | Depends on Picture Mode |
| Sharpness | Depends on Picture Mode |
| Color | Depends on Picture Mode |
| Tint | Depends on Picture Mode |
| Reset Video Settings | No |

| | |
|----------------------|---|
| Audio | |
| Sound Mode | Standard |
| Balance | 0 |
| Sorround | Off |
| Internal Speakers | Auto |
| Digital Output | RAW |
| Audio Input | When Input (HDMI1) : HDMI 1 |
| | When Input (HDMI2) : HDMI 2 |
| | When Input (HDMI3) : HDMI 3 |
| | When Input (VGA) : Audio in |
| | When Input (AV) : AV |
| | When Input (Media Player) : Media Player(Fixed) |
| Audio Delay | 0 |
| Reset Audio Settings | No |

Setup

OSD Settings

| | |
|-----------------|---------|
| Language | English |
| Transparency | Off |
| Information OSD | On |

Power save settings

| | |
|-----------------|----------|
| Energy Mode | Home |
| Power Save | 1 minute |
| Quick Start | Off |
| Auto Power Down | Off |

| | |
|-------------------|------|
| Auto Input Change | None |
|-------------------|------|

HDMI Settings

| | |
|----------------|---------|
| CEC | |
| CEC | On |
| Auto Turn Off | Enable |
| Audio Receiver | Disable |
| EDID | Mode 2 |
| Video Range | Auto |
| HPD Delay | Off |

VGA Options

| | |
|---------------------|--------------------------|
| VGA Mode | RGB |
| Auto Adjust | Press OK to execute |
| Horizontal Position | Depending on Auto Adjust |
| Vertical Position | Depending on Auto Adjust |
| Clock | Depending on Auto Adjust |
| Phase | Depending on Auto Adjust |
| H. Resolution | Depending on Auto Adjust |
| V. Resolution | Depending on Auto Adjust |
| Reset VGA Options | No |

Other Settings

| | |
|--------------------|----------------------------|
| Input Labels | Same as Input Name |
| Key Lock Settings | Off |
| IR Lock Settings | Off |
| Power Supply | Off |
| LED Indicator | On |
| Mute Settings | Audio |
| Image Rotation | Off |
| Thermal Management | |
| Warning Message | On |
| Shutdown | On |
| Signal Information | Depending on source signal |

| | |
|---------------------|----------------|
| Monitor Information | Depends on set |
|---------------------|----------------|

| | |
|---------------|----|
| Factory Reset | No |
|---------------|----|

| Control Settings | | |
|----------------------------|--------------------------------------|-------|
| Control Interface | | LAN |
| Network Settings | | |
| DHCP | On | |
| IP ADDRESS | xxx.xxx.xxx.xxx | |
| SUBNET MASK | xxx.xxx.xxx.xxx | |
| DEFAULT GATEWAY | xxx.xxx.xxx.xxx | |
| DNS PRIMARY | xxx.xxx.xxx.xxx | |
| DNS SECONDARY | xxx.xxx.xxx.xxx | |
| MAC ADDRESS | Individual | |
| SAVE | Press OK to execute | |
| Monitor ID | 1 | |
| Reset Network Settings | No | |
| Media Player | | |
| USB Demo Mode | Off | |
| UnPlug USB Device | Enabled when USB device is attached | |
| Caution Window | On | |
| Schedule | | |
| Sleep Timer | Off | |
| Current Time settings | Current time and date can be changed | |
| Schedule settings (1 to 7) | | |
| Power On | Mark (Disable) | |
| Time | | 12:00 |
| Power Off | Mark (Disable) | |
| Time | | 12:00 |
| Every Day | Mark (Disable) | |
| Every Week | Mark (Disable) | |
| Mon | Mark (Disable) | |
| Tue | Mark (Disable) | |
| Wed | Mark (Disable) | |
| Thu | Mark (Disable) | |
| Fri | Mark (Disable) | |
| Sat | Mark (Disable) | |
| Sun | Mark (Disable) | |