





Adjust Focus
 Régler la mise au point
 Stellen Sie den Fokus ein
 Ajuste el enfoque
 Regolare la messa a fuoco
 Ajuste da focagem
 Pas de scherpstelling aan
 Wyreguluj Ostrość
 Настройте фокусировку
 Projektorin tarkennuksen säätö


Justera fokus
 Juster fokus
 Juster Fokus
 Προσαρμογή Εστίασης
 Élességállítás
 Upravít zaostření
 Odağı Ayarla
 调整焦距
 초점 조절
 ضبط البؤرة



Toggle Output Settings

Dell	[Fn] + [F8]
Hewlett Packard	[Fn] + [F4]
Lenovo	[Fn] + [F7]
NEC	[Fn] + [F3]
Toshiba	[Fn] + [F5]

Macintosh Apple :
 System Preferences ⇒
 Display ⇒ Arrangement ⇒
 Mirror display



P/N 36.76002G001-A

7N8N5831

© NEC Display Solutions, Ltd. 2015

Ver. 1 4/15

Printed in China